

CC-1 Crystal Core Installation Guide

Installation Guide 4th December 2006 Version 1.0 Table of Contents

Setting up the Computer

Installation information is based on a Dell Precision[™] 390 Workstation



Hardware requirements

Processor:	Intel Dual Core - 1866MHz (L1 cache: 32.0 Kb, L2 cache: 2.00 Mb, L3 cache: 0 Kb)
	Ext.clock: 1066 MHz - Intel $^{\circledast}~$ 975X Express chipset. (Dell offers Dual-Core Intels on this system ranging from 1.86GHz a 2.93GHz)
Bios:	Phoenix ROM BIOS PLUS – please use Version 1.10 1.0.5 (01-Sep-2006)
Memory:	2.00 Gb (2 095 124 Kb) 2 X 1024 Mb (DDR2, Synchronous,1 MHz) EEC – unbuffered.
Video 1:	NVIDIA GeForce 6600 (256.0 Mb) - Leadtek Research.
Drivers:	ForceWare Release 90 Version: 91.47 Release Date: September 14, 2006 WHQL Certified
Video 2:	Matrox G550 PCI-Express x1, 32MB, DualHead, 2 x DVI. (required if DryIce embedded video option is chosen)
Sound card:	SigmaTel High Definition Audio CODEC
Network:	Broadcom NetXtreme 57xx Gigabit Controller
OS:	Windows XP Professional English 5.1 (build 2600 Service Pack 2)



Hard Drives

Your Fairlight CC-1 System should already have been configured according to the following: The CD-ROM has been removed Apart from the System Hard Drive, 3 extra SATA drives have been added to the system. 2 are used as Audio Drives, 1 is used as a Video Drive.

The 2 Audio Drives have been mounted using 2 Serial SATA 3.5" HD Mobile Racks & Removable Trays. *See photo.*



We have used the following drives for this: Western Digital - MODEL: WD1500ADFD

SATA Hard Drive / 150 GB, 1.5 Gb/s, 16 MB Cache, 10,000 RPM.

The Dell 390 has an Integrated SATA 3.0Gb/s controller with support for RAID 0, 1, and 5.

These 2 Audio drives have been set up as <u>2 striped drives</u> – RAID 0, using Windows Drive manager.

BIOS settings must be set accordingly ... Please go into Bios Setup <F2>

- § Go to <Drives>
- § Please enable all SATA devices (0,1,2 & 3) Set to <ON>
- § Please disable all PATA devices (0 & 1) Set to <OFF>
- § For "SATA Operation" please set to <RAID Autodetect / ATA>
- § Smart reporting should be set to <OFF>

Please save these Bios settings and restart the computer.

An Additional drive for Video has been added in the Dell's secondary hard-drive bay (see below).



Any SATA hard drive may be used for this ... 7200 RPM or above. 8Mb cache minimum.

System Board Components / Card Layout

The Dell[™] computer provides the following slots for PCI and PCI Express cards:

- § Three PCI card slots
- § One PCI Express x16 card slot
- § One PCI Express x8 card slot (wired as x4)
- § One PCI Express x1 card slot



Important

DO NOT INSTALL the CC-1 card <u>until all other devices</u> with their respective drivers are all properly installed, Bios is correctly upgraded, and the computer is running happily and strong.

Note: We have also observed that some "stock" DELL Windows XP installations require a **complete** XP re-install in order to correctly accept the CC-1 card. Please use the DELL reinstallation CD ... ; install required drivers (Network card & Audio / <u>Intel Chipset Software</u> must be also installed)... update BIOS, and appropriate Nvidia and Matrox drivers before proceeding.

CC-1 Card/Software installation:



Step1 Shutdown the computer.

Step2 Install the CC-1 card into the PCI-E (4 lane slot)

Step3 Power on the computer.

Step4 Windows will detect the card as a "default" à <u>PCI to PCI Bridge</u> (Found new hardware PCI device) and bring up the installation Wizard:

Step5 Hit <Cancel>.



Step6 Now install Dream_II_vxxxx_setup.exe (appropriate DREAM II installer). Use all defaults. However, when you see the following page ... please untick <Program Crystal>.



Step7 Browse to Start/All Programs/Fairlight/Dream II/Dream II Utils/ ... and click on <Install Crystal Drivers>.



You will be prompted to add these components to the Windows registry. Click $\mbox{<Yes>}$

Step8 Browse to Start/All Programs/Fairlight/Dream II/Dream II Utils/ ... and click on <Program Crystal>. This will automatically "Flash" the CC-1 with the appropriate CORE.

This takes about 15-20 seconds. You will observe a "DOS" window displaying FLASH progress.



Step9

Turn off Windows visual effects ... Browse to **à** Control Panel/System Properties/Advanced/Performance/Visual Effects ... and Tick <Adjust for best performance>.

Confirm with <OK>.



9

- C:\WINDOWS\WinSxS

Step 10 **Only** If it is a full and clean install from "scratch" on the PC ... There is one more "manual" operation to do before you launch DRYICE for the first time.

Step 10 Please go to the FTP site and download the file WinSXS.zip.

Use the new DryIce ftp area at ftp.fairlightau.com:

Username=dryice

Password=snowflake

Please extract this file (keeping the embedded tree structure) to:

C:\WINDOWS\WinSxS

Surface Setup

Step 1 Browse to: Start/All Programs/Fairlight/FMC/FMC Utils/Surface Manager



Step 2 Launch the application: This should look very familiar ... as this is now the equivalent to "DreamStart".

		Sec. Star
Surface Manager	and the second	×
Surface Status:	USB Panels are all OK	
Panel T Console Configuration	2	
Console Type Station		efresh
Panel Id Panel Type		program
	Add Panel	Config
	Modify Panel	DVG-w
	Delete Panel	
	Remove All	California de la calegaria de
Add New Panel		and the state of the
Panel 1 OK	ОК	
SatellitePanel2 Cancel	Cancel	
		Evit
		and a state of the state of

Panel Type	PanelId	Version	CPU	Status	
SatellitePanel2	Panel 1	4, 2.06	2	Running OK	Refresh
					Reprogram
					Edit Config
					USB View
					Class
-					Close

This is where you can set up your appropriate panels and surface types.

Step 3 Hit <Edit-Config> ... to start setting up your panels and surface type.

Please note that for **Satellite II** ... you should use Console type "Station" / Panel 1 / and "type" **SatellitePanel2** ... as seen above. If you see that the firmware for this Panel is "older' than 4,2.06 (or if you get a firmware error) please highlight the panel and <Reprogram> using the dedicated button. You can calibrate "as usual" <Shift-PauseBreak-C> once the application is up and running.

Please note that there is no longer a need to "Save" the configuration ! Surface setup using this new utility should be very straightforward J

Setting Up Graphics/Displays

On a system that has been pre-configured by Fairlight, you should not have to change your graphics settings. But you will need to set up your graphics again if you change your screen settings or graphics card.

Some graphics caveats:

- **§** The graphics card must be 256 MB minimum.
- **§** The graphics card should be low profile, or it will cover the adjacent PCIe slot ! USE THE CARD SUPPLIED BY FAIRLIGHT until further notice! *See specs page1.*
- **§** The FMC screen must run on the low-res output at 16 bit color. This is typically the <u>VGA</u> <u>connector</u> on the NVidia card, or the <u>BOTTOM DVI</u> connector on the Matrox card.
- **§** The DryIce Screen must run on the hi-res output at 32 bit color. This is typically the <u>DVI</u> <u>connector</u> on the NVidia card. This DryIce Screen **always** needs to be the "Primary monitor".
- § Both screens must run at 1280 x 1024.
- § If you run the NVidia in horizontal span mode (for video screen), resolution must be 2560 x 1024. The DryIce "embedded" Video display is the <u>VGA output</u> on the NVidia
- **§** NVidia cards must see monitors ON POWER UP. Connecting monitors after power up, even followed by a restart, is pointless. Power down, connect, power up.

Positioning the FMC screen

Step 1	Make a copy of the existing - C:\Program Files\Fairlight\FMC\Data\System_Variables.txt
Step 2	Open C:\Program Files\Fairlight\FMC\Data\System_Variables.txt in WordPad
Step 3	Remove the lines 'WINDOW_X1, WINDOW_Y1, WINDOW_X2, WINDOW_Y2'
Step 4	Change 'HAS_FRAME' to 1
Step 5	Save and close C:\Program Files\Fairlight\FMC\Data\System_Variables.txt
Step 6	Run up Drylce, which will start FMC.
Step 7	Drag the FMC Window to the appropriate display in the correct position.
Step 8	Click on FMC, then press <shift+pause break=""> followed by 'a'</shift+pause>
Step 9	Quit FMC.
Step 10	Open C:\Program Files\Fairlight\FMC\Data\System_Variables.txt in WordPad
Step 11	Change 'HAS_FRAME' to 0
Step 12	Make sure 'SCREEN_NUMBER' of FMC matches the number of your screen (as shown in Windows Display Properties). **Note**: monitors in horizontal span mode are "seen" as a SINGLE monitor!
Step 13	Save and close C:\Program Files\Fairlight\FMC\Data\System_Variables.txt

We will work on streamlining this procedure. Keep in mind that you DO NOT have to do this on a working setup. DO NOT TRY THIS if you don't need to, and the procedure WILL NEVER WORK if your displays are not set up correctly per the graphics caveats.

Afterwards you can go into System_Variables.txt and edit the <u>following lines</u> to get a real "tight fit" on the FMC mixing screen. Here are the best results we have found so far:

WINDOW_X1,-1280 WINDOW_Y1,0 WINDOW_X2,-1

WINDOW_Y2,1024

Notes

There is another possibility for Graphic setup, but this can be a bit more expensive. This involves using directly a Quadruple head graphics card.

A card that gas been tested is the NVIDIA Quadro NVS 440. (NVIDIA Quadro NVS 440 by Leadtek)

		Desktop Series	
PRODUCT	NVIDIA Quadro NVS 280	NVIDIA Quadro NVS 285	NVIDIA Quadr NVS 440
Memory Size	64MB DDR	64MB DDR 128MB DDR2	256MB ² DDR
Memory Interface	64-bit	64-bit	128-bit
Bus Interface	PCI-32	PCI Express x1 PCI Express x16	PCI Express x1 PCI Express x1
Form factor	SFF	SFF'	ATX Full Height, 1/2 length
Display Connectors	DMS-59 (1)	DMS-59 (1)	DMS-59 (2)
Max Displays per Board	2	2	4
Max Digital Display Support	1600 x 1200	1920 x 1200	1920 x 1200
Max Analog Display Support	2048 x 1536	2048 x 1536	2048 x 1536
Max Power Consumption	21W-Passive	21W-Passive	31W-Passive
NVIDIA nView Enabled	Yes	Yes	Yes
NVIDIA TurboCache	No	Yes	No

This card has the obvious advantage of having 4 independent display outputs directly on the card and it uses only one PCI Express x16 slot.



General Connection/Setup Information



FAIRLIGHT CC-1 Media Technology Platform for the 21st Century

CC-1 and SX20

The connection needed between the CC-1 card and the SX20 requires a DVI-I dual link cable – male to male.



These are relatively easy to find, but in most cases, are not available in stores and need to be ordered. We have seen cables that are up to 15- feet / 5 Meters in length.

Satellite II connections / USB ...

The Sat II is equipped with a standard USB 1.1 Type B connector on the back.



This can be used <u>directly</u> if needed ... The max cable length between a USB computer and this USB interface is 5 meters (16.5 feet). If you need longer ... Here is our suggestion.

USB Ranger 110/410 pair - this allows you to extend your USB to 100meters à from Icron.

http://www.icron.com/

This is the technology that we already license from ICRON to make the USB extreme card.

http://www.icron.com/products/usb/usb_products.php

Constellation XT/Anthem connections

You will need to fit on or more "USB extreme card(s)" into one or more of the PCI slots of the DREAM II PC.

Extreme USB Connection

Your Extreme USB cable is provided by Fairlight. It is a standard Ethernet cable terminated by RJ-45 connectors. At the PC end, plug it into the connector shown below.

If your system is a Station, simply plug the other end into the RJ-45 connector at the rear.

Talkback	US	B Extreme In - R.	J45	Şta	ition
\$		Į	1		
• • •	0	•		USB Cables for	Panels

If your system is a ConstellationXT or Anthem, the surface will be open during installation. The Extreme USB cable is normally passed up one leg of the console, after coming through the floor, and should then be connected to the RJ-45 connector on the BMIX002A circuit board.



Rear view of the BMIX002A circuit board, showing the RJ-45 connector at the right.

Information

Extreme PCI is a Fairlight method of carrying many USB signals down one cable. It uses a standard Ethernet cable, and connects to a dedicated card in your DREAM II PC. If your DREAM II system is a 5-bay Constellation/Anthem, your PC will be configured with two Extreme USB cards, and you will be supplied with two cables.

DREAM II Utilities. (for Service Technicians)

There is a folder here **à** C:\Program Files\Fairlight\DreamII Utilities\; This folder contains some useful diagnostic tools:

§ Crystal Test – To simply verify that your Crystal Core Card is "running" correctly, please launch CrystalTest ... verify that Hardware Type, Revision, Firmware Class and Firmware Build are clearly indicated, and that the "Master Clock" is running as seen below.

C:(Program Piles)/Fairlight(Dream II Utilities)(Crystal	Teat	
Grystellest		
and Fulder Tasks		
Parate the file	🖞 CrystalTest	
Nove this file		
Copy this file	Hardware Tana di Santana	
Publish this file to the Web	Hardware lyper 3 Heisteri 1	
E-mail this file	Persware Claim: 1 Persware Build: 77 Control	
Delete this file		
and the second	01:00:04:01	
100		
er Places	Home Parts 00/17/46/21	
Overam II (JORdes	ASSETUCE OF PROPER	
My Documents		
Shared Documents	Rev Play Hag Hag Hag	
Ny Computer		
Ny Network Flamm		
	Charles Information Information	
	CHIEF THE CONTRACT OF THE CONTRACT.	
tails (2)	Annual Instantian Day day death	
	Lest and the sector of the sec	
	LEDWIERCE BEVAL ENTRY	
	EMM write: 0 react 0	
	Rec09/1	
	Internet Statement Internet in a sub-	
	card offset (
	PC affast a	
	to d'shift	
	Ender Crudda _ Edd Die Edd D - Paperborn 1	
	Antiparticipant and and and and	
	Son Senal Driver Ditertace	
	Promotion Property 028	
	UrS/HLIS	
		1

ATTENTION : Please do not tamper with other functions of this test program, as these are used for advanced diagnostics and "playing around" with these parameters could endanger the card.

§ SX20 Test – This is a diagnostic utility for the SX20 ... stay tuned, full documentation pending.

Cr/hispon File/Forlight/Jo	ean I Utiliter/Sila	allex.																					_	_
f folder Tasks 🛛 🖄 S	X-20 Test																							
overtis Re estis Flo w Re Se Abstris Floro try Art all the Flor Britlis Flo Britlis Flo	Crista Hardware Tvo Rinware Das SVX Rinware Bulk	ei t Fi t		Re Fri Si	/box marel Mvare	audi 3 Buidi	T					[Sent -e Rus Sch Ret Film	6 8 8									-	
1 mm	They f	Releyscher	165 	P	91) 977) 18	E S E S	de 1 Chek	Г ri Г H	w 1	- 14	di.													
Documents-	Rook,Ward	E Ph	_	5150			220	5	ATE															
				10%	6	- Est	530																	
ent Documents	46.1	E to	52,	- 754						2722														
ecil Documento Consecor Norvoli, Tierco	4% i	- to 		- 41	ан 811		к:	1	No F	F	MISC MISC	4	19672		1947	77	1	Ń	6	L	1.16	an.	lin.	
erd Documento Consecer Remotil Namo	4%	- Po - WA	1	-41	611		4	1	No C No C	F	MINC MINC	4	1967		1947	7.7		515	6	1	-	olti a	lin	
ed Docarento Dinacon Norvolti Reno (V	4%	- Po 	1	-41			n. Jarda		wa F wa F		MISC MISC	4	1907		1947	,,	nue	n dou	6.:	_	-	catra a	lin	
er Documenta Sentano Remonit Tarca V	4%	T Po with molegies (^	-41		· ·	n and As	uni At	Na F Na F		ares ares	Å	1907 ^A 1;	d'o	1947 ^2 L	0°2	200	n dae	4. 4		0.0	ora o	7	
of Documents Consuce Konold, Tecco U	4%	Trailog is 1 Histog is 2	, , , , ,	-41 1 2 1 2	**		ь лов ^5 Г ъ	uni Ac	Wull Wall		Miss Miss	1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1	1907 ⁶ 1; * 1;	d'o ru	1942 ^2 L ^ L	P 2	2000		4 4 4		0 I	orana P	7	
iel Dozanisti Solakor Konsek Neces	LPL 1 4% Nove Dg3a > D	File Makegin 1 Reaktyo 7	21 -1 -1	-41 -72 -73	** **	·• ·•	4 As C 5	uni Ae Ce	Nu F Na F Na F		ыны ыны (*) (*) (*)		1907 ⁴ 1. * 1. * 1.	ifo na na	1947 ^2 L ^ L ^ L	Pr 2	- 2 0 C C		•		1 0° 1 1		7 7	0.0
ind Documents Scrature Kongel, Necos	Life 1 4% Stee Dyba > D D > Anales	F fo wak wakojin 1 krakojin 2 krakojin -	21 		** ** **	· · · · · · · · · · · · · · · · · · ·	4 As C 5 C 5	uni Ae Ce			4750 AND C		1967 ^A L ^C L ^C L	1 ⁴ 0 7-12 7-12 7-12	1997 1 ² 1 1 ⁻¹ 1 ⁻¹	0 r 2 r 2	- 200 C C C		4 / / 4 / /				7 7 7 7 7 7 7 7 7	0.0
rel Dougentes Deser Nordel Teros U	time dos Doka SD D > Anales D > Metany	F fo wak makegin 1 inskepin 2 inskepin 2 jadod in 1		-40 1 2 1 2 1 2 1 2		****	4 A C 5 C 5 C 5				4790 1610 1610 1610		1907 1 ⁻¹ L 1 ⁻¹ L 1 ⁻¹ L 1 ⁻¹ L	1 ⁴ 0 7-12 7-12 7-12 7-12	1942 1 ² L 1 ² L	0 - x - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2 - 2	- 20° 0 0 0 0		6 • / • / • /				1 m 7 m 7 m 7 m 7 m 7 m 7 m 7 m 7 m	0 0 0 0 0
el Dozarda. Inner Ieroef, Tero	t fin i 4% been Dybes > D D > Analies D > Network	The set of	1 			· · · · · · · · · · · · · · · · · · ·	ы А Св Св Св Св		940 944 944 944 944 944 944 944 944 944		4950 163 163 163 163		1907 ^A L ^C L ^C L ^C L ^C L	1 ⁴ 0 7-12 7-12 7-12 7-12	1997 1 ² 1 1 ² 1 1 ² 1 1 ² 1 1 ² 1 1 ² 1				•					
ee Docamenta Contaco Norman No	Life i 4% Digita > D D > Anales D > Hetere	F Po Web Madogin 1 Readogin 2 Readogin 2 Readogin 2 Readogin 2 Readogin 2 Readogin 2 Readogin 2				···	ы Аз Сз. Сз. Сз. Сз.		940 Mai C + 1 C + 1 C + 1 C + 1 C + 1 C + 1		4900 AN		1987 1 ⁴ 1. 1 ⁶ 1. 1 ⁶ 1. 1 ⁶ 1. 1 ⁶ 1.	с ги ги ги ги	1997 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	р Гг Гг Гг Гг Гг			• • * * * • * *				7 1 7 1 7 1 7 1 7 1 7 1 7 1 7 1 7 1 7 1	0 0 0 0 0 0 0

§ SX20 Flash – With certain DREAM II software updates, it will be necessary to "flash" the actual SX20 firmware. There is a program located in C:\Program Files\Fairlight\DreamII\SX20 Flash\ that permits you to do this.

The Flash program uses the CC1 card and the DVI cable to program the on board flash of the SX20. So have the sx20 connected and powered up, but close DryIce/DreamII software that will want to talk to the CC1. Close the DreamII program and launch sx20-flash.

You will get a report about your Crystal core.

Hit "program Flash" - the flashing green led on the sx20 should go out until programming is complete.

The sx20 should re-start immediately.

The whole thing will take about 40 seconds.

5 🛅 C:\Program Files\Fairlight\Dr	am II\SX20 Flash	2
and Folder Tasks 🔹	國 sx20.rpd 黔 SX20-Flash	
Rename this file Move this file	🔒 SX20-Flash	
Copy this file Publish this file to the Web E-mail this file Delete this file	Program Flash	001 Crystal Card detected 002 Type: 43981, Rev: 43981, Class: 43981,
er Places 🙁		
Dream II My Documents Shared Documents My Computer My Network Places	Cancel	ОК

Joe Hammer / FairlightAu December 06